DIY ESP32 Smart Clock Guide



Version V1.5 By Gray

TABLE OF COMTENT

1.	Introduce	3
2.	Features	3
3.	Diagram	4
4.	Part list	6
5.	Soldering	7
	5.1 Soldering tools	7
	5.2 Insert electronic component	7
	5.3 How to solder	8
6.	Usage	11
	6.1 Assembly	
	6.2 Clock usage	11
Not	e_1	15
Not	e_2	18

1. Introduce

This interesting kit provides all the parts to DIY an on-line clock& weather station in 1~2 hours' learning of soldering& programming, could be a good first step to IOT projects for the electronic hardware learners& Kids.

The circuit board is based on ESP32, which support Arduino programming easily, all the necessary components, such as OLED display, buzzer, button are include in the kit, the users can solder them on the board manually, to enjoy the joy of DIY. Makerfabs provides firmware that can be upload to the board, to make the boards as a world clock, weather station. It is funny and exciting that DIY a smart clock of your own.

To reduce the difficulty of soldering, all SMD components are pre-soldered, it will take about 2 hours to solder this kit.



2. Features

- ESP32 WROOM module: WiFi, Bluetooth, 4MB Flash
- 1.44inch 128*128 color display, ST7735 driver
- Buzzer*1
- Button*3
- Micro USB interface
- Support Arduino
- 450mAh battery, support charge.
- Plug-in components, easy soldering.
- Spent about 2 hours soldering









4. Part list

Name	Quantity	Designator
Resistance 1KΩ	6	R1,R2,R7,R11,R12.R18
Resistance 2KΩ	1	R8
Resistance 4.7KΩ	4	R3,R6,R9,R10
Resistance 10KΩ	4	R5,R14,R15,R16
Resistance 470Ω	1	R4
Electrolytic capacitor 10uF	4	C1,C3,C4,C5
Ceramic capacitor 100nF	2	C2,C6
2-pins Female Header	1	J1
Buzzer	1	BUZZER
Button	3	S1,S2,S3

5. Soldering

5.1 Soldering tools

Below outline the tools and materials you will need for this project soldering.

- 1. Solder
- 2. Soldering iron
- **3.** Cleaning sponge
- 4. Soldering iron stand
- 5. Cutting plier



5.2 Insert electronic component

Start the soldering by inserting the electronic component into the pads of the circuit board, The order of the component to solder is determined by the high of the component It is highly recommended to insert resistors in the pads and solder them firstly. When the lower height component (as resistor) been welded, they will not hinder the soldering of other components (such as capacitor). After the low components inserted, follow the below steps to solder them and cut out the extra lead.



Height

Note that the electrolytic capacitor and buzzer are polar. Refer to the polarity marking and on-board marking to insert the component, as the picture.



5.3 How to solder

- 1. Safety first!
- Hold the soldering iron like a pen and near the basic of the soldering iron. Don't touch the iron anywhere when the soldering is on or hot.
- Placed the soldering iron to the stand when the soldering iron is in idle.
- 2. Below shows how to solder one lead of the electronic component (such the resistor):
- Begin by inserting the lead into the hole of the circuit board.



- Turn on your soldering iron and let it heat up.
- Hold the soldering iron in one hand and solder in the other.



• Touch the tip of the soldering iron to the copper pad and the resistor lead. Hold the soldering iron in place for seconds to heat the connection. Both parts that are being soldered have to be hot to form a good connection.



• Touch the solder to the joint, not the soldering iron directly.



- Remove the soldering iron and let the solder cool down naturally.
- Cut down the excess pinout.



• A proper solder joint is smooth, shiny and looks like a volcano or cone shape.



- 3. If the iron tip is surrounded by oxide during the soldering, use the wet sponge to wipe it directly for clean which is helpful for soldering, though it will cause the tip cold.
- 4. It hard to avoid the bad connection between paths forming when soldering first time, don't worry and it is easy to fix.
- If the place where the pad and lead meet wasn't heating enough, it would form a bad connection. Place the solder iron to heat again and the solder will flow naturally to form a good connection.
- If the solder is not enough, place the soldering iron where the connection to heat, close the solder to add a little one.
- If the solder over-flow the welding pad, it may cause a short circuit when the solder touch other pad. It is necessary to remove the solder.

6. Usage

Power on the board (plug the USB cable or battery), press the button to on, the display will be light on. It means the board can work normally.

6.1 Assembly

There are acrylic shells and screws/ stands to package the PCBA and battery:



6.2 Clock usage

Set the ESP32 WiFi credential for connecting WiFi.

When turning the power button on, press the button(S1) and hold it in 1S;



• Release the S1 button, use mobile phone or PC to connect the WiFi "Makerfabs_ap".



• Type the IP "192.168.4.1" to Chrome or other browsers on your phone to enter the server.

15:54		····· :페 49% =		
\$	192.168.4.1	C		
Makerfabs				
ESP32 WIFI CONFIG				

• Input your WiFi credential to the server, ESP32 will connect to WiFi after a minute.

Makerfabs	☆! № 2# 49% 篇
ESP32 WIFI CONFIG	
SSID: PASSWORD:	
Set	

• As WiFi connection setting finished, it will record the setting and connect the WiFi automatically. If the WiFi setting need to be updated, follow the above steps to retype WiFi credential again.

Clock

• After the WiFi setting or powering again, you will see the time shown on the display.



• The number in the bottom of right is the alarm time, and the point before the alarm time indicates that the alarm is activated. Press S3-button to disable the alarm.

Alarm

• Press the S1-button to change the page to Alarm setting.



- Press S2-button to select the hour or minute.
- Press S3-button to add one to the value.
- When the alarm is ringing, press any button to pause it.



Time zone

• Press the S1-button to change the page to Alarm setting.



- Press the S3-button to modify the time zone to you want.
- When you finish the change, reset the board and the settings would take effect.

Weather

• Press the S1-button to change the clock page, the LCD will show the local weather, temperature and humidity.



• you can press the S3-button to navigate the cities you pre-set in the firmware

The DIY is finish, enjoy!

Note_1

Makefabs DIY ESP32 Clock Kit is open hardware& firmware, if you would like to program& download& update firmware , please follows the steps below:

- 1. The firmware can be obtained from github: <u>https://github.com/Makerfabs/Makerfabs_SmartClock_Kit</u>.
- 2. Install Arduino IDE on the PC.
- 3. Use the USB cable to connect the board and PC. Turn the power button to ON.





- 4. Open Arduino IDE, install the package support the ESP32 for work. The link provided the detail how to install the ESP32 package: https://github.com/Makerfabs/Makerfabs_FAQ/tree/master/Arduino_ESP32
- 5. Select the development board and port.

SmartClock A	Arduino 1.8.10		
File Edit Sketch	Tools Help		
	Auto Format Archive Sketch	Ctrl+T	
SmartClock	Fix Encoding & Reload		
1 #includ 2 #includ	Manage Libraries Serial Monitor Serial Plotter	Ctrl+Shift+I Ctrl+Shift+M Ctrl+Shift+L	ST7735
3 #incluo 4 #incluo	WiFi101 / WiFiNINA Firmware Updater		
5 #inclu	Board: "ESP32 Dev Module"	>	Boards M
6 #includ 7 #includ 8 #includ 9	Upload Speed: "921600" CPU Frequency: "240MHz (WiFi/BT)" Flash Frequency: "80MHz" Flash Mode: "QIO" Flash Size: "4MB (32Mb)"	> > > >	Arduino L Arduino L Arduino/(Arduino E
1111#1nclui			Arduino M

Arduino 1.8.10		
Tools Help		
Auto Format	Ctrl+T	
Archive Sketch		
Fix Encoding & Reload		
Manage Libraries	Ctrl+Shift+I	
Serial Monitor	Ctrl+Shift+M	
Serial Plotter	Ctrl+Shift+L	ST / / 35
WiFi101 / WiFiNINA Firmware Updater		
Board: "ESP32 Dev Module"	>	
Upload Speed: "921600"	>	
CPU Frequency: "240MHz (WiFi/BT)"	>	
Flash Frequency: "80MHz"	>	
Flash Mode: "QIO"	>	
Flash Size: "4MB (32Mb)"	>	
Partition Scheme: "Default 4MB with spiffs (1.2MB APP/1.5MB SPIFFS)	• >	
Core Debug Level: "None"	>	
PSRAM: "Disabled"	>	
Port: "COM11"	>	Serial ports
Get Board Info		✓ COM11
Programmer: "A\/RISP mkll"	>	

6. Enter the library manager, type "Adafruit_GFX" to Install the library "Adafruit_GFX.h".

SmartClock Are	duino 1.8.10			
File Edit Sketch	ools Help			
	Auto Format		Ctrl+T	
	Archive Sketch			
SmartClock	Fix Encoding & Reload			
1 #inclu	Manage Libraries		Ctrl+Shift+I	
2 #inclu	Serial Monitor		Ctrl+Shift+M	ST773F
2 #inclu	Serial Plotter		Ctrl+Shift+L	517750
4 #inclu	WiFi101 / WiFiNINA Firmwa	ire Updater		
5 #inclu	Board: "ESP32 Dev Module		>	
6 #inclu	Upload Speed: "921600"		>	
7 #inclu	CPU Frequency: "240MHz (WiFi/BT)"	\$	
8 #inclu	Flash Frequency: "80MHz"		\$	
o #incia	Flash Mode: "QIO"		\$	
9	Flash Size: "4MR (32Mb)"		2	
Library Manag Type All	yer ✓ Topic All	✓ Adafruit GFX		×
More Into		- 1		
				~
Adafruit GFX Libra	ary by Adafruit Version 1.10.4 I	NSTALLED	hics libraries derive from Insta	I this library in addition to the
display library for y	your hardware.	e class that all our other grap	incs indianes derive from. Insta	in this library in addition to the
More info				
Select version	· ✓ Install			Update
Adafruit ImageRe	ader Library by Adafruit			
Companion library for Addrivit_GFX and Addrivit_EPD to load images from SD card. Install this library in addition to Addrivit_GFX and the				
display library for your hardware (e.g. Adafruit_ILI9341), plus the Adafruit_SPIFlash library and SdFat.				
Adafruit NeoMatri	ix by Adafruit			

Follow this step to install the libraries: "Adafruit_ST7735.h" and "ArduinoJson.h"

7. And set the cities you would like for weather info (Newyork, London, Beijing, Paris by default), you can add some more cities there, please check this <u>list</u> for supported cities:



8. Click the Verify button and Upload button to load the code.



9. Reset the board.

Note_2

The default firmware only support Newyork, London, Beijing and Paris, to customize the weather forecasting for your city, you can reprogram to support more cities.

Beijing	Newyork	Moscow
Shenzhen	Los Angeles	Roman
Seoul	Vancouver	Venice
Bangkok	Mexico	London
Singapore	Mumbai	Paris
Macau	Tokyo	Istanbul

To follow cities are supported:

.

The below shows how to confirm the city which you would like to get the weather information that could be added to the code (such as add the city "Macau").

• When I would like to get the Macau weather, Replace the "**Newyork**" with "**Macau**" in the following link:

https://free-

api.heweather.net/s6/weather/now?location=**Newyork**&key=2d63e6d9a95c4e8f8d3f 65d0b5bcdf7f&lang=en

the result:

https://free-

api.heweather.net/s6/weather/now?location=**Macau**&key=2d63e6d9a95c4e8f8d3f65 d0b5bcdf7f&lang=en

Copy the result link to the browser, if it will get the information, it is OK.



• Fill the "Macau" to the code.

```
40 cuon_liag = 0;
49 cation_index = 0;
50
51 weather_location[] = {"Macau", "London", "beijing", "paris"};
52
53 etup(void)
54
```